

Xskinz.com

Installing The Tops CJ and YJ (1987-1991)



Insert the top into the windshield channel.

Secure the center strap next.

Snap the buttons. (As shown below. Buttons are not used on 1987-1991 YJ models.)

Insert each side's back straps into the little bracket on the back of your Jeep. Connect the strap through its buckle and tighten down each side. Tighten straps a little at a time on each side to make the top evenly taut on both sides.

Use two hands to tighten the back straps down.

Fasten the velcro straps around the roll bar pads.



NOTE: we do not supply the bracket shown below.

